

EHE6899SA

Connected 681L natural stainless steel French door refrigerator featuring a FlexFresh fully convertible entertainer's drawer, SmartSplit door design and TasteLock Easy-glide crispers with automatic humidity control.

RRP AUS \$4,499.00





# **Product Details**

## FEATURES

FlexFresh™ Fully Convertible Entertainer's Drawer	SmartSplit Door Design	Connectivity	Mark resistant real stainless steel	
Filtered ice and water	Slide-back and Flip-up shelving	SnackZone	UltraChill	
Drinks Storage	Snacks Storage	FlexStor Its never been easier to get organised with our door compartment storage system. By simply lifting and sliding, you can adjust the height and position of the door compartments to fit both small and large items. With FlexStor you can change the configuration whenever you need to customise your refrigerator.	FreshPlus Cooling Keep your food at its best with our innovative FreshPlus technology. Whenever the fridge door is open, it immediately begins recooling to replace the lost cold air.	
Quick freeze function great for when a large quantity of food is added to the freezer	reat for when a largeAfter a large grocery shop,uantity of food is added touse the Boost function when		Electronic controls with LED display and acoustic signal Electronic controls with LED display and acoustic signal	
Holiday mode Going away? Set the fridge to Holiday Mode to help minimise defrosting and save energy.	R600a refrigerant better for the environment	LED lighting	Frost free Save your precious time with a freezer that doesn't ice up and need manual defrosting.	



Fresh Sense deodoriser Keep your fridge and its contents smelling fresh with the in-built Fresh Sense deodoriser.

# BENEFITS

#### A place for everything

We've thought long and hard about what you need in a fridge. Which is why you'll find a host of ingenious zones to help you organise your drinks and other items and even adjust microtemperatures for perfect cooling. The FlexFresh fully convertible entertainer's drawer lets you dial up or down the cold air from -23C to +7C so your creation is revealed at its best. Likewise, you can store your drinks in the special drawer and set the temperature for perfectly chilled champagne or ice-cold drinks. Store your go-to essentials in a special SnackZone for the ultimate in organisation.

#### Intuitive door design

With optimally split doors you have more usable space in your refrigerator door and can effortlessly reach for larger items, saving you the need to open both doors every time.

#### Fresh is best

Our innovative TasteLock crispers automatically control the humidity levels to keep your fruit and vegetables at their best for longer. While Easy-glide crisper drawers open effortlessly, even when they're full.

#### Connectivity

Fresh ingredients form the most important part of every meal. With the new Electrolux Life app, you can confidently know that your produce is in the desired conditions by being able to monitor & adjust its temperature from the palm of your hand. Set your Entertainers Drawer to the right temperature when you're out gathering fresh produce, and receive alerts through the app when the desired temperature is reached. Ensure you always have fresh filtered water, as you get a reminder when its time to change the filter cartridge, or an alert when the door is accidentally left open. Let the refrigerator do the thinking so you can effortlessly plan your next get together.

#### Stylish and smart

High quality, mark-resistant real stainless steel, now available in a new chic dark hue or classic natural stainless steel, lends a touch of class to any kitchen. Inside, the generous interior marries innovation and style in equal measure.

#### Connectivity Terms & amp; Conditions

Minimum requirements: iPhone6/iOS 9.3/Android 5.1 and above. You will need to install the Electrolux Life app, create an Electrolux account and accept the Terms and Conditions and Electrolux's Privacy Policy in the app to use the connected features of the appliance. Internet and Wi-Fi connections are required to use the full features of the app and the appliance. Minimum requirements, apps and services are subject to change without notice.

# Electrolux

# EHE6899SA

#### Thirst-quencher

Like a cool glass of pure, filtered water? Your fridge is there to deliver, any time of the day or night at the touch of a button.

#### Ice on the go

You'll love the efficient, always-ready ice-maker in your new fridge. Efficient and compact, it's ideal for hot summer days or effortless entertaining.

#### Smart on space

The thoughtful Slide-back and Flip-up shelving means you can store that two-tiered birthday cake for the big moment, no problem.

#### SnackZone

The SnackZone is the ideal compartment for keeping those smaller ingredients separate for easy access such as fruit for your morning smoothie allowing you to be prepared before the week begins.

#### Designed just for you

Customise your fridge just the way you want it. FlexStor™ makes it simple to arrange the fridge to your needs with adjustable door bins and shelves. Different sized compartments effortlessly accommodate items big or small.

#### Keep it cool

UltraChill

The fridge door is one of the most opened in any household, which is why we came up with FreshPlus technology to help maintain the perfect temperature inside your fridge. It automatically detects when it needs to begin cooling, keeping the temperature down to lock the freshness in.

The UltraChill setting is a deep chill at -2C which keeps meat

and fish fresh in optimum condition for longer without freezing.

This ensures the fresh texture is maximised and moisture loss

is reduced compared to regular deep freezing. This saves your

time defrosting meat and more time to enjoy with your guests.

#### Increase the chill

With a combination of Quick Freeze and Boost mode, you will always be prepared when entertaining. After a large shop, Boost Mode increases the chill rate of the refrigerator for 6 hours whilst the Fast Ice function lowers the freezer to -23C for 12 hours, before returning to their pre-set temperatures, to ensure your produce stays fresher longer.

#### Snacks Storage

Store your specialty meats and cheese at 3C, the ideal temperature for storing your antipasto platter, ready to be enjoyed when your guests arrive.

# Effortless access

It is one of the most hardworking appliances in your house, so it makes sense your fridge takes the effort out of simple tasks. Our smooth telescopic runners ensure you can reach the very back of the crisper and freezer drawers easily.

# Drinks Storage

Store your drinks at the ideal temperature every time by setting the drawer at 7C for perfectly chilled wine and champagne, or at 0C for icy cold drinks.

### TwinTech Cooling System

Two independent cooling systems work together to deliver lasting freshness. One cooling system chills the freezer so no frost builds up. The other cools the refrigerator, providing stable temperature and humidity.



# **Specifications**

# PRODUCT PROFILE

Domestic warranty details (yrs)	2	
Additional domestic warranty for the sealed refrigeration system only (yrs)	3	
Refrigerator Type	french door	
Exterior door finish	Stainless steel	
Handle design	integrated	
Fridge door opening	left and right	
Cooling system	frost free	
Freezer door opening	drawer	
Refrigerant	R600a	
Dispenser type	ice and water	
Plumbed water supply required	Yes	

## DIMENSIONS

Total height (mm)	1782
Cabinet height (mm)	1756
Total width (mm)	913
Cabinet width (mm)	908
Total depth (mm)	746
Cabinet depth (mm)	625
Depth door open 90degree (mm)	1189
Air space above cabinet (mm)	25
Food compartment capacity (gross in litres)	413
Freezer compartment capacity (gross in litres)	188
Total Gross Capacity (L)	681
Convertible Compartment/Drawer capacity (gross in litres)	80
Food compartment capacity (net in litres)	363



Energy Star Rating AS/NZS 3

## DIMENSIONS

Total Net Capacity (L)

541

## ENERGY

4474.2:2009

(kWhr/yr)

Energy consumption

AS/NZS 4474.2:2009

REFRIGERATOR SYSTEM

Controls	electronic (with display)		
Controls location	internal		
Controls type	touch		
Control functions	quick freeze function,quick chill,lock,ice maker,wi-fi connected		
Door alarm	fridge and freezer		

# FOOD COMPARTMENT

SHELVING	
Shelf material	glass
Type of shelf	spill safe shelf,adjustable shelf
Flip up shelf	1
1/3 width shelves	1
2/3 width shelves	1

560

# CRISPERS

Crisper lid/shelf	plastic
Crispers Runner system	telescopic
Crisper features	automatic humidity control,fully sealed
1/3 width crisper	1
2/3 width crisper	1

# Electrolux

## LIGHTING

 Feature lighting
 LED

 Main light
 LED

# OTHER PROPERTIES

Other Properties-FOOD COMPARTMENT

Egg tray, Snack zone

# FOOD COMPARTMENT DOOR

BINS	
Deep bottle bin	1
Shallow bin	2
1/3 width bins	1
Expandable bin	1

## DAIRY COMPARTMENT

Half width, with lid

# SPECIAL COMPARTMENTS

Small items bin

# EXTERNAL

Dispenser through door

ice and water

1

# FREEZER COMPARTMENT

ICE FACILITY

Ice Maker

Automatic

1

# BASKET/DRAWER

Full width plastic basket

Basket/Drawer runner system

telescopic

1



# EHE6899SA

Drawer divider	2
Full width deep plastic basket	1

# LIGHTING

Main light

LED



# Dimensions



Front face of bench aligned to front corner edge of cabinet.

French door with convertible	Door width	Total depth	Maximum	Cabinet	Cabinet depth	Depth door
drawer models:	(W)	(D)	height (H)	width (W1)	(D1)	open (D2)
EHE6899SA, EHE6899BA	913	746	1782	908	625	1189

For connection kit installation instructions go to electrolux.com.au

Important! Please ensure that the access to your kitchen (including doorways, corridors, island benches, etc) allows sufficient clearance to move your fridge into position. Please note! Dimensions to be used as a guide only. All customers MUST refer to the user manual supplied with the product for detailed installation instructions.



# **Terms and Conditions**

#### IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

#### **PRODUCT INFORMATION**

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous productdevelopment, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes theproducts that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products PtyLtd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours ofproducts illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

#### WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

#### ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640 fax: 1800 350 067 email: customercare@electrolux.com.au web: www.electrolux.com.au

#### ELECTROLUX HOME PRODUCTS NEW ZEALAND telephone: 09 573 2230 fax: 09 573 2221 email: customercare@electrolux.co.nz web: www.electrolux.co.nz