


Anti-flood Inlet Hose - 1.5m

Peace of mind with anti-flood technology

ULX105




DESCRIPTION


To safeguard your home, the anti-flood inlet hose stops water instantly at the tap if the hose bursts or is leaking. The hose features a small indicator light, which is green when the hose is intact and turns red if a leakage occurs. Suitable for washing machines and dishwashers.

The hose is a convenient 1.5m in length.

Available at leading electrical retailers



INSTALL



CONTENTS

1 x Anti-flood inlet hose – 1.5m

INSTRUCTIONS

- Simple to install
- Securely screw to your water outlet ensuring no twists or kinks in the hose (as per diagram)
- Monitor the attachment at first use to ensure there are no leaks

TIPS

- To avoid personal injury, use correct equipment and ask for assistance when moving appliances

SUITABLE FOR MOST BRANDS INCLUDING:

AEG	LG
Dishlex	Miele
Electrolux	Samsung
Westinghouse	Siemens
	SMEG
Ariston	Whirlpool
Beko	
Bosch	
Euromaid	
Fisher & Paykel	
Gorenje	
Haier	

GET IN TOUCH WITH US

For more information on all UNILUX accessories, phone or email our customer care teams

AUSTRALIA

1300 363 640
customer@electrolux.com.au
uniluxaccessories.com.au

NEW ZEALAND

0800 234 234
customer@electrolux.co.nz
uniluxaccessories.co.nz