


## Hot or Cold Water Inlet Hose - 2m

**When you spring a leak or just can't reach**

ULX107



### DESCRIPTION

This inlet hose for dishwashers and washing machines is flexible and adaptable.


- Replace an old leaking hose
- When your standard hose just won't reach

Suitable for use with hot or cold water inlet taps.

Features straight end to hooked end with couplings.



### INSTALL



### CONTENTS

1 x Flexible inlet hose - 2m

### INSTRUCTIONS

- Simple to install
- Securely attach to either the cold or hot water inlet on your washing machine or dishwasher ensuring no twists or kinks in the hose (as per diagram)
- Monitor the attachment at first use to ensure there are no leaks

### TIPS

- To avoid personal injury, use correct equipment and ask for assistance when moving appliances

### SUITABLE FOR MOST BRANDS INCLUDING:

AEG  
Dishlex  
Electrolux  
Westinghouse

Ariston  
Beko

Bosch  
Euromaid  
Fisher & Paykel  
Gorenje  
Haier  
LG  
Miele

Samsung  
Siemens  
SMEG  
Whirlpool

### GET IN TOUCH WITH US

For more information on all UNILUX accessories, phone or email our customer care teams

### AUSTRALIA

1300 363 640  
customer@electrolux.com.au  
uniluxaccessories.com.au

### NEW ZEALAND

0800 234 234  
customer@electrolux.co.nz  
uniluxaccessories.co.nz